

9077 | INSTALLATION

1. BEING CUATIOUS NOT TO DAMAGE PAINT/POWDER, REMOVE ALL SARAN WRAP.
2. INSTALL (6) FOOTPADS TO THE MACHINE AS SHOWN BELOW.

HOME



PARTS SELECTION